

INSTALLATION GUIDE

Harlequin Cubicle Range

(Nursery & Infant height only; for Junior see relevant material range guide)

- Locate partition centres using a plumb line or spirit level, mark all partition centres on rear wall.
- Fix rear wall cleats to the wall at heights of 312mm and 1100mm from centre of the cleat to finished floor level. Use 6 Nr. 1½" Zinc plated c/sunk screws and red plugs. Ensure all wall cleats are vertically aligned.
- Fit the adjustable leg to the partition and secure with 'T' bolts using the Allen Key provided
- Slide partition into cleats on rear wall and support on the base 150mm above floor level. Position & centre front of partition to required location and mark around the leg on the floor. Slide partition out of the way and secure leg block to the marked circle on floor.
- Slide partition into fixed wall cleats and fit pedestal leg over leg block on the floor. Level partition using the leg pin and secure using "T" bolts.
- Fit pilaster cleats to intermediate pilasters in pre-drilled pilot holes using Nr.8 BZP c/sunk screws.
- Fit pilasters to partitions using double 'T' bolts.
- Fix the wall pilasters to the wall ensuring they are vertical, match the height of the intermediate pilaster and line through with the front of the intermediate pilasters. Set the wall cleats at the same height as the dividing partition and use 6 Nr. 1½" c/sunk Nr.8 screws to secure to the wall. Secure the pilaster to the wall cleats using the double 'T' bolts supplied. These holes to be drilled on site.
- Measure the overall width of the cubicle range and cut the headrail as required. Any cut edges to be fitted against the wall. If more than one headrail is required, ensure the angle is cut to join over an intermediate pilaster and the centre of the partition. Fit the headrail by drilling 2mm holes through the headrail vertically into the top of the pilaster. Secure the headrail with 5/8" Nr.6 pozi pan screws (2Nr per pilaster). Ensure that all components are level in all directions.
- Fit the indicator bolt on the door ensuring the bolt is fitted to the correct handing. All doors are viewed from the outside, i.e. With hinges on the right & indicator bolt on the left (opening as a right hand door). Fit the hinges to the door by dismantling hinge then fit 'U' cleat over pre-drilled hole and screw in threaded rod. When secure drill a 3.5mm pilot hole in door and secure with Nr. 10 x 25mm screw, the hinges may be adjusted to fall open or closed by rotating the position of the opaque nylon cams. Do this procedure at this stage.
- Fit the female hinge to the pilaster using a No.10 x 18mm chipboard screw in bottom hole of hinge and a countersunk 'T' bolt through top hole of hinge. Hang door by lifting the male locating pin into the female hinge on the pilaster. Secure hinges by installing the machine screw to the male pin once located in the female hinge section.
- Working from the inside of the cubicle, fully extend the indicator bolt and position the keep. Ensuring the bolt is fully engaged, mark and drill 2 Nr. 3.5mm holes. Fit indicator bolt keep. Position and fit rubber buffers using twinfast screws.
- Fit coat hook to rear of the door using 2 Nr. 4.2mm x 15mm self-tappers.
- Mark and fit toilet roll holder to partition using Nr. 8 c/sunk BZP twinfast screws.